



Repair Movies, Mechanical

Applicable for G700

CONTENTS

1	Read this first!	2
2	Movies	3
	2.1 Disassembly	4
	2.2 Reassembly	5
3	Revision history	6

1 Read this first!

After downloading and extracting the Repair Movies zip file, you will get access to this PDF document, the FEA document 'Repair Movies, Mechanical'.

To watch the repair movies, Flash Player version 6 or later must be installed on your computer. The Flash Player can be downloaded free of charge from www.adobe.com.

By clicking on the pictures with blue borders in the Movies section, the repair movies will be shown in an Internet Explorer window.

However, when running the movies on a Windows XP computer with Service Pack 2 installed, the movies become blocked each time you try to access them and will not be launched until you have accepted to unblock the content and then again confirmed the action.

To avoid this, you can adjust your computer's security settings in the following way:

- open Internet Explorer
- click Tools / Internet Options / Advanced, and scroll down until you find Security
- check the box with the text 'Allow active content to run in files on My Computer'

NOTE!

Do not change this setting unless you are aware of how this will affect the security of your computer!

After having the first movie window opened, you should adjust the size of the Internet Explorer window until it looks like the adjacent picture example.

Furthermore, the movie can be controlled with the help of three buttons and a slider handle, as follows:

1. Go to the beginning of the movie
2. When running - 'Freeze' the picture
When 'frozen' - Start running from current position
3. Go to the end of the movie
4. Slide the handle to any wanted part of the movie
or use it as a slow motion 'scrubber'



NOTE!

These Repair Movies are to be regarded as a supplement to and not a substitute for the Working Instruction.

When watching these movies you should have the Working Instruction available as well, since the Working Instruction is a document with lots of information not being included in the Repair Movies.

2 Movies

The movies are divided into the same three categories as in the Working Instruction:

- Disassembly
- Replacements
- Reassembly

Most of the Replacements instructions are quite easy to carry out, so just a few of them are available as movies.

All Disassembly and Reassembly instructions are covered by the movies, where each movie includes several separate instructions of the Working Instruction, as listed below the movie headings.

2.1 Disassembly

Battery Lid Asm & Battery
Stylus
Antenna Lid Asm
Frame Sub Asm
Front Cover
Key Board
Speaker Box
M2/SIM Sub PBA
Flash Flex Carrier
LCD Carrier & LCD
PBA



2.2 Reassembly

PBA
LCD & LCD Carrier
Flash Flex Carrier
M2/SIM Sub PBA
Speaker Box
Key Board
Front Cover
Frame Sub Asm
Antenna Lid Asm
Battery & Battery Lid Asm
Stylus





3 Revision history

Rev.	Date	Changes / Comments
1	2008-05-15	Initial release